



Use and Care Guide



Bathroom Fan Vent Kit



TOOLS REQUIRED



Caulking gun




Phillips screwdriver

HARDWARE REQUIRED (NOT INCLUDED)



Screws (4)




Latex caulking

Installation


1 ASSEMBLING THE ALUMINUM PIPE

- Press the sides of the aluminum pipe together and lock them into place.




2 ATTACHING THE VENT CAP TO THE PIPE

- Attach the vent cap to the pipe. Ensure the pipe fits snugly inside the collar. Align the clips on the collar (A) so they snap into the pipe slots (B).




4 INSTALLING THE EXHAUST HOOD

- From the outside, pass the pipe through the hole opening until the vent cap lies flush against the outside wall surface. Secure the vent cap to the wall by screwing it into place and/or caulking around the reveal.



5 ATTACHING THE DUCT TO THE TAILPIECE


- Extend the duct, and measure it to cover at least 2 in. of exhaust tailpiece. Cut off any excess duct, and secure this end with the clamp.



3 CUTTING A HOLE THROUGH THE WALL


- Cut a 4 1/4 in. diameter hole through the wall, or insert a window plate with a 4 1/4 in. diameter hole.

NOTICE: Ensure the appropriate tool is used to cut the hole in the wall according to the type of wall material.



6 ATTACHING THE DUCT TO THE BATHROOM FAN

- Slide one end of the duct over the exhaust outlet of the bathroom fan, and secure it with the adjustable clamp.



Note

If bathroom fan exhaust collar is 3 in., then wrap the self adhesive foam increaser strip around it before attaching the duct to it.

Warranty

WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

WHAT IS NOT COVERED

This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance visit www.DundasJafine.com.